

everything *Mary*®

Hardware
How to...


Purse Frame

Tools/Supplies Needed:


- Paper
- Pencil
- Round Needle
- Embroidery Floss

Instructions:


1. To add frame to a coin purse, trace the outside of the frame to a sheet of paper.




2. Draw the rest of the coin purse.



3. Then transfer the pattern to your fabric and lining material.
Sew seam on wrong side of fabric and turn.



4. Sew lining and insert in coin purse. Insert the top of the coin purse into the frame.



5. Using a round needle and embroidery floss, sew through the holes for a nice finished look.

